



3/8" IMPACT SOCKET SETS

Model	Type	Contents
SS3012	12 pc STD	5/16" to 1"
SS3012D	12 pc DEEP	5/16" to 1"
SS3113	13 pc STD	7-19mm
SS3113D	13 pc DEEP	7-19mm



1/2" IMPACT SOCKET SETS

Model	Type	Contents
SS4013	13 pc STD	7/16" to 1-1/8", 1-1/4"
SS4013D	13 pc DEEP	7/16" to 1-1/8", 1-1/4"
SS4114	14 pc STD	10-19, 21, 22, 26, 27mm
SS4114D	14 pc DEEP	10-19, 21, 22, 26, 27mm



3/4" IMPACT SOCKET SETS

Model	Type	Contents
SS618	8 pc STD	26, 27, 29, 30, 32, 35, 36, 38mm
SS618D	8 pc DEEP	26, 27, 29, 30, 32, 35, 36, 38mm
SS6014D	14 pc DEEP	3/4" to 1-1/2", 1-5/8"

1" IMPACT SOCKET SETS

Model	Type	Contents
SS808	8 pc STD	7/8" to 1-1/4", 1-1/2"
SS808D	8 pc DEEP	7/8" to 1-1/4", 1-1/2"
SS818	8 pc STD	27, 30, 32, 33, 35, 36, 38, 41mm
SS818D	8 pc DEEP	27, 30, 32, 33, 35, 36, 38, 41mm
SS8205WS	5 pc TRUCK	DP 33mm, 1-1/2", 13/16" Sq, DP TW 1-1/8", 1-1/4"
SS8210HDW	10 pc TRUCK	DP 33mm, 1", 1-3/16", 1-1/2" SPL, 1-3/4", 13/16" Sq, 15/16" Sq, DP TW 1-1/16", 1-1/8", 1-1/4"

SPECIALTY SOCKETS

Model	Description
S412x13FD	1/2" DR Standard Flip, 3/4" x 13/16" - Thinwall
S412x13FTW	1/2" DR Standard Flip, 3/4" x 13/16" - X-Thinwall
S414x15FTW	1/2" DR Standard Flip, 7/8" x 15/16" - Thinwall
S419x21MFD	1/2" DR Standard Flip, 19mm x 21mm - Thinwall
S419x21MFETW	1/2" DR Standard Flip, 19mm x 21mm - X-Thinwall
LT-1240	1/2" DR Flip, 21 x 21.5mm (Chrysler / Dodge)
LT-1250	1/2" DR Flip, 18.5 x 19.5mm (GM & Chrysler)
LT-1260	1/2" DR Flip, 22 x 22.5mm (Chrysler / Dodge)
LT-1270	1/2" DR Flip, 27 x 27.5mm (Range Rover / Land Rover)
S824D	1" DR, 1-1/2" Deep
S833MD	1" DR, 33mm Deep
S835MD	1" DR, 35mm Deep
S841MD	1" DR, 41mm Deep
S824x13BW	1" DR, Budd Wheel, 1-1/2" Hex & 13/16" Square
S81316SQ	1" DR, Budd Wheel, 13/16" Square



**COMPLETE LINE OF CHICAGO PNEUMATIC
IMPACT SOCKETS AVAILABLE**

7835 SOCKET SET

- 1/2" Drive, 5 pc set: 17, 19, 21mm, 13/16" and 7/8"
- Features protective sleeves and internal plastic inserts that prevent scratching of wheels and decorative lug nuts
- Hollow design creates room for removing longer bolts by pushing out plastic insert
- Blow molded case