



TIRE STORAGE RACKS

- Racks come in 2 styles:
 - Single entry:** mounts against the wall - access from one side
 - Double entry:** freestanding - access from both sides
- Support bar height is adjustable
- Starter racks include 2 ends and support bars
- Adder racks include 1 end and support bars
- Wall mounting hardware included with single entry racks



Starter Tire Rack				Adder Tire Rack			
Single Entry Tire Rack							
Model	No. of tiers	No. of tires*	Size WxDxH	Model	No. of tiers	No. of tires*	Size WxDxH
R2-2SES	2	16	5' x 1' x 5'	R2-2SEA	2	16	5' x 1' x 5'
R2-3SES	3	24	5' x 1' x 7'	R2-3SEA	3	24	5' x 1' x 7'
R2-4SES	4	32	5' x 1' x 10'	R2-4SEA	4	32	5' x 1' x 10'
R2-5SES	5	40	5' x 1' x 12'	R2-5SEA	5	40	5' x 1' x 12'
R2-6SES	6	48	5' x 1' x 15'	R2-6SEA	6	48	5' x 1' x 15'
Double Entry Tire Rack (R2-4DES Shown)							
Model	No. of tiers	No. of tires*	Size WxDxH	Model	No. of tiers	No. of tires*	Size WxDxH
R2-2DES	2	32	5' x 3'6" x 5'	R2-2DEA	2	32	5' x 3'6" x 5'
R2-3DES	3	48	5' x 3'6" x 7'	R2-3DEA	3	48	5' x 3'6" x 7'
R2-4DES	4	64	5' x 3'6" x 10'	R2-4DEA	4	64	5' x 3'6" x 10'
R2-5DES	5	80	5' x 3'6" x 12'	R2-5DEA	5	80	5' x 3'6" x 12'
R2-6DES	6	96	5' x 3'6" x 15'	R2-6DEA	6	96	5' x 3'6" x 15'

*Tire quantity depends on tire size



1278 TIRE DISPLAY

- 2 Tier, 4 caster unit with sign bar
- Fits up to 10 tires per tier
- Shown with optional locking bar & sign



1278 TIRE DISPLAY

- 2 Tier, 2 wheel unit with sign bar
- Fits up to 10 tires per tier
- Shown with optional sign
- Use the 1898 tote jack for easy movement around the shop or lot



1898 TOTE JACK

- For moving tire displays 1278 & 1804
- All-steel, welded construction
- Gloss black weather-resistant baked enamel finish
- Heavy-duty 10" ball bearing wheels

1804 TIRE DISPLAY

- 3 tier, 2 wheel (16" pneumatic) unit
- Fits up to 10 tires per tier
- Shown with optional sign & sign bar
- Use the 1898 tote jack for easy movement around the shop or lot
- UPS shippable



TC400 TIRE CART

- Foot-operated lever adjusts arms to handle 23" thru 35" diameter tires
- Gas spring automatically closes the arms that grip the tires - all you have to do is push down on the pedal, slide the cart into the stack of tires, and release the pedal
- Semi-pneumatic tires



EZ-1FT TIRE CART

- Handles 23" thru 36" diameter tires
- Foot pedal actuated positive lock
- Semi-pneumatic tires

